

**READ  
THIS.**

**THANK YOU!**

Got your attention? Great! There's more —>

Congrats on your purchase with Echo Technologies™! We are delighted to play a role in your health journey. Here are a few things you should know about your new Echo H2 Machine™.

- The Echo H2 Machine™ should be cleaned at least once per year. If you live in an area with hard water, it should be cleaned more regularly (every three to six months). For easy cleaning, purchase a Cleaning Cartridge (for Echo H2 Machine™).
- If you are installing your Echo H2 Machine™ under your counter, you will need an Echo H2 Faucet™. The Echo H2 Faucet™ is a vented faucet that is designed to work with the Echo H2 Machine™. It has three water lines: red, blue, and white. It protects your machine from excess water pressure.
- If you are installing your Echo H2 Machine™ above your counter, you will want to use the Diverter Valve. This valve connects to your faucet, and when turned on, it diverts water from the faucet to the machine.
- The Echo H2 Machine™ comes with an internal filtration system. You will need to regularly change the internal filter. To do this, open the door on the back of the machine, push down on the top of the filter, and pull it out.

Please refer to the Echo H2 Machine™ Instruction Manual included, for more information on installation.

If you have any questions regarding your Echo H2 Machine™, please don't hesitate to contact our Customer Support Team at [support@echoh2o.com](mailto:support@echoh2o.com) or by phone at (855)737-1114.

